


NORMAC FLEX-Riser – Anodeless Design

the better way to connect natural gas supply


The NORMAC
FLEX-Riser
makes
installations
easy as 123!



- 1) Connecting the PE Pipe is a snap. Installers run their PE Pipe through the FLEX-Riser casing to its above-ground fitting on the meter end, then up through the connecting FLEX-Riser casing to its above-ground fitting on the appliance end.
- 2) Bending the FLEX-Riser's flexible steel casing simplifies the work to adjust it in the trench.
- 3) Tightening the assembly with just two pipe wrenches provides a reliable seal. *See installation instructions .

<u>Model #</u>	<u>Pipe Size:</u>
FR593WOB	1/2" - SDR 9.3
FR-10-11-WOB	3/4" - SDR 11
FR-19-36-11	1" - SDR 11
FR-2-10-WOB	1 1/4" - SDR 10
FR-2-11-WOB	1 1/4" - SDR 11
FR21	1 1/2" - SDR 11
FR-22-36LB	2" - SDR 11





ATTENTION INSTALLER!

USE TWO

NORMAC FLEX-Risers

**One FLEX-Riser
at the Meter End
and
One FLEX-Riser
at the Service End
Eliminates
Underground
Joints**



Service End:
Pool/Spa/Garage Heater
Natural Gas Grill

House/Meter End

One Continuous Length of PE Pipe and Two Anodeless FLEX-Risers

